

Champ Deluxe Mobile Masker

Part #6266 Assembly Instructions



CHAMP®








Made In USA

Champ Frame Straightening Equipment, Inc.

Parts List

- (A) - Left Side Brace (viewed from the front) w/Foot
- (B) - Right Side Brace (viewed from the front) w/Foot
- (C) - Basket
- (D) - (4) Caster Wheels
- (E) - Plastic Sheeting Box Top Plate w/Magnet Strip
- (F) - Blade Post
- (G) - Plastic Sheeting & Paper Roll Poles
- (H) - Lower Brace
- (I) - Middle Brace
- (J) - Upper Brace
- (K) - Post for Plastic Sheeting Pole
- (L) - Post for Paper Roll
- (M) - Bottom Tray
- (N) - (3) Blades
- (O) - (4) Tape Hubs
- (P) - (8) Locking Collars
- (Q) - (8) Large Washers
- (R) - (8) Springs
- (S) - Nuts, Bolts & Washers




I n s t r u c t i o n s




- 1.** Attach each foot to the left and right sides



- 2.** Join both sides together by attaching the lower brace (H) to each side



- 3.** Attach the middle brace (I) to the second holes down, from the top of the masker



- 5.** Attach the bottom tray to the lower back of the masker



- 4.** Attach (4) wheels



- 6.** Attach the basket (C) to the top holes of the masker



- 7.** Attach the blade post (F) to the rear left side (viewed from the rear) of the masker

I n s t r u c t i o n s



Figure 1



Figure 2




Figure 3



Figure 4

- 8.** Slide the shorter pole (G) (figure 1) through the plastic sheeting box and install onto the right side of the lower rear tray on the back of the masker. Place the top plate (E) (figure 2) on the top of the box. Attach post (K) to the middle brace (I) (figure 3). Attach the pole (G) to the post (K) (figure 4)




Upper
Brace J

- 9.** Attach upper brace (J). This brace bolts to the blade post (F) on the left side and post (K) on the right side



Figure 1



Post L

Figure 2

- 10.** Attach the longer pole (G) to the left side of the lower rear tray on the back of the masker (figure 1) and then attach post (L) to the upper brace (J) and to the pole (G) (figure 2)



Figure 1





Figure 2



Tape Hub Locations



Figure 3

- 11.** Attach (3) blades (N) (figure 1), (4) tape hubs (O) (figure 2) and locking collars, springs and washers (figure 3)

Just load your paper rolls and tape, and your Champ Deluxe Mobile Masker is ready to be used!